

A Quick Start To  
**TINALab II** FPGA Development Kit



## OVERVIEW

The TINALab Spartan-II FPGA Development Kit provides an easy-to-use, low-cost evaluation platform for developing designs and applications based on the Xilinx Spartan-II FPGA family.

The kit can be physically connected to the User Port of TINALab II or can be used stand alone with an external power supply, a Xilinx JTAG programming cable and the free Xilinx ISE WebPACK software. The board is mounted with a 144-pin TQFP (thin quad flat-pack) Xilinx Spartan-II device (up to 100,000-gate XC2S100-5TQ144) gives users high performance, abundant logic resources, and a rich feature set. Features include block RAM, distributed RAM, 16 selectable I/O standards, and four DLLs.


If you use TINALab Spartan-II together with TINA circuit simulation software and TINALab II High Speed Multifunction PC Instrument there is possible to develop VHDL code with simulation capabilities and after implementing, you can download your design and measure back the signals with the help of TINALab II Digital Signal Generator and Logic Analyzer. TINA provides code developing, simulation and measurement control with TINALab II, which does power supplies and signal link.

Forty-two user I/O signals from the FPGA are connected to user headers. The board includes the XCF01S ISP configuration Xilinx Platform Flash, a JTAG header, and a configuration mode connector, an on-board socketed clock oscillator, VGA, PS2, RS-232 serial port, four seven-segment LEDs, user LEDs, slide switches, and push buttons.


## HIGHLIGHTS OF TINALAB SPARTAN-II FPGA DEVELOPMENT BOARD


- XC2S100-5TQ144 FPGA, system performance supported up to 200MHz operation
- Xilinx XCF01S 1Mbit Platform Flash Configuration PROM for non-volatile designs
- JTAG-programmable
- On-board 1A voltage regulators (2.5V core, 3.3V I/O)
- JTAG programming port
- 50MHz SMD crystal oscillator
- Socket for a second oscillator
- 92 user I/O's routed to on-board devices and three expansion connectors
- 9-pin RS-232 Serial Port
- PS/2-style mouse/keyboard port
- 6-bit, 64-colour VGA display port
- Ladder R/2R 4-bit DAC
- 8 individual LEDs
- 4-digit seven-segment display
- 4 momentary-contact pushbuttons
- 8 slide switches

# TINALAB SPARTAN-II DEVELOPMENT KIT CONNECTED TO TINALAB II



# VHDL DESIGN FLOW





## ONBOARD HEADERS AND CONNECTORS

<b>J1</b>	<b>TINALab II Logic Analyzer</b> Note, if you do not use the Logic Analyzer then J1 can be used as generic User I/O.
<b>J2</b>	<b>TINALab II Digital Signal Generator Connector</b> Note, if you do not use the Digital Signal Generator then J2 can be used as generic User I/O.
<b>J3</b>	<b>User I/O</b> Note, - that if you apply Slave Parallel configuration mode then J3 is the byte-wide data and miscellaneous control during the configuration.
<b>J4</b>	<b>TINALab II User Port Connection</b>
<b>J5</b>	<b>9-pin RS232 serial port</b>
<b>J6, J7</b>	<b>N.C.</b>
<b>J8</b>	<b>External power supply connector (+5V)</b>
<b>J9</b>	<b>Multilink connector (JTAG, configuration link, JTAG chain broker)</b>
<b>J10</b>	<b>PS2 port</b>
<b>J11</b>	<b>VGA port</b>
<b>JP1</b>	<b>Power supply and configuration jumper</b> Close pin 1-2 to be powered by TINALab II, 2-3 by external +5V.
<b>JP2</b>	<b>FPGA configuration jumpers</b>
<b>JP3</b>	<b>R/2R Ladder DAC output</b>
<b>JP4</b>	<b>PROM interface jumper</b>
<b>JP5</b>	<b>PS2 port supply voltage jumper</b>

## CONFIGURATION SUPPORT

Configuration is the process by which the bitstream of a design, as generated by the Xilinx development software, is loaded into the internal configuration memory of the FPGA. The TINALAB Spartan-II Development Board supports several different FPGA configuration modes, which are described below.

When you use TINALab FPGA board with TINALab II the board is powered, configured, driven and measured by the instrument. Without TINALab II, you need a +5V external power supply and configuration hardware (see [http://xilinx.com/products/design\\_resources/config\\_sol/index.htm](http://xilinx.com/products/design_resources/config_sol/index.htm)). At the end of the configuration flow FPGA drives DONE high and board DONE LED (D2) goes up.

## TINALAB II USER PORT

When you use TINALab FPGA board with TINA and TINALab II, a 2x7 ribbon cable provides connection from the instrument to the board J4 block header connector. TINALab II supplies the board with power and configures the FPGA in slave serial mode. To set up, follow these steps:

1. Remove connections from J9 header pin 2, 6, 8, 10 and J3.
2. Remove external power supply plug from J8.
3. Open all the jumpers of JP2 (Slave Serial mode)
4. Close JP4 pin 2 to 3 and JP1 pin 1 to 2
5. Switch off TINALab II
6. Connect TINALab II User Port to that of TINALab FPGA card (J4) with the 14-wire wide cable
7. Connect TINALab II Digital Outputs to the TINALab II Digital Signal Generator Connector (J2)
8. Connect TINALab II Digital Inputs to the TINALab II Logic Analyzer Connector (J1)
9. Switch on TINALab II

## USING THE TINALAB FPGA BOARD WITHOUT TINALAB II


When you use TINALab FPGA board without TINALab II, FPGA can be configured using one of the four Spartan-II configuration modes: slave/master serial, slave parallel and Boundary Scan (JTAG) mode. The Configuration mode pins (JP2: M2, M1, M0) select among these configuration modes with the option in each case of having the IOB pins either pulled up or left floating prior to configuration.

Configuration mode	Preconfig pull-ups	M0	M1	M2
Master Serial	No	0	0	0
Master Serial	Yes	0	0	1
Slave Parallel	Yes	0	1	0
Slave Parallel	No	0	1	1
Boundary Scan	Yes	1	0	0
Boundary Scan	No	1	0	1
Slave Serial	Yes	1	1	0
Slave Serial	No	1	1	1

In any case, remove TINALab II User Port Connection if it has been used before and close JP1 pin 2 to 3 for the powering. The other steps are depending on the configuration method found in detail the later description. In every mode the last step is to connect the external power supply.


**JTAG CHAIN**

Multilink connector provides connection to the board JTAG chain, as shown below. Opening the J9 pin 12 and 14 can break the JTAG chain. Using flying JTAG cable leads to intercept either the ISP FLASH TDO or the FPGA TDI. Set JP2 configuration mode pins in Boundary scan mode.



**SLAVE SERIAL**

In serial slave mode, the FPGA is configured by external configuration hardware, e.g.: Xilinx Parallel Cable IV connected Multilink connector (J9) as shown below. Open all JP2 jumpers and close JP4 pin 2 to 3.



**MASTER SERIAL**

In Master Serial mode, the CCLK output of the FPGA drives the Xilinx PROM, which feeds a serial stream of configuration data to the FPGA’s DIN input. According to the mode set JP2 and close JP4 pin 1 to 2.

## SLAVE PARALLEL

The Slave Parallel mode is the fastest configuration option. Byte-wide data is written into the FPGA through the Multilink and J3 connector. Set JP2 and close JP4 pin 2 to 3.

## USER RESOURCES

### CLOCK SOURCES

A 50 MHz SMD oscillator (mounted on the bottom side of the PCB) provides the primary clock source for the TINALab FPGA Board. A second 3.3V oscillator can be plugged into an on-board 14-pin socket. The socket accepts either full- or half-can oscillators. With a 50 MHz clock source, the user can take advantage of the Spartan-II FPGAs internal clock management block, the DLL. The Spartan-II DLL can deskew an incoming clock across the FPGA, providing zero delay with respect to the user source clock. The DLL can provide multiple phases of the source clock. The DLL can also act as a clock doubler, or it can divide the user source clock by up to 16.

NET "CLK" LOC = "P88";	On-board SMD oscillator (Y2)
NET "GCK3" LOC = "P15";	Socketed 3.3V oscillator (Y1)

### PUSH BUTTONS

The Spartan-II development board design provides four push button switch inputs to the Spartan-II FPGA. Each push button switch can be used to generate an active low signal. When the switch is pressed, FPGA input connected to ground (logic low), when released, internal Spartan-II pull-ups are required to generate logic high. Any push button can be designated to be a RESET signal into the FPGA.

Note, there is a fifth button labeled PROG (SW1), which is used to initiate a configuration sequence when pushed. It is not intended to be a general-purpose input.

NET "push<0>" LOC = "P139";	Push button 0 input
NET "push<1>" LOC = "P138";	Push button 1 input
NET "push<2>" LOC = "P137";	Push button 2 input
NET "push<3>" LOC = "P136";	Push button 3 input
NET "push<0>" PULLUP;	Internal pull-up resistor
NET "push<1>" PULLUP;	Internal pull-up resistor
NET "push<2>" PULLUP;	Internal pull-up resistor
NET "push<3>" PULLUP;	Internal pull-up resistor

## SLIDE SWITCHES

The TINALab FPGA development board provides eight slide switch inputs. These switches can be statically set to a low or high logic level. When the switch is disconnected from ground (logic low), internal Spartan-II pull-ups are required to generate logic high.

NET "switch<0>"	LOC = "P11";	Slide switch 0 input
NET "switch<1>"	LOC = "P12";	Slide switch 1 input
NET "switch<2>"	LOC = "P13";	Slide switch 2 input
NET "switch<3>"	LOC = "P19";	Slide switch 3 input
NET "switch<4>"	LOC = "P23";	Slide switch 4 input
NET "switch<5>"	LOC = "P22";	Slide switch 5 input
NET "switch<6>"	LOC = "P21";	Slide switch 6 input
NET "switch<7>"	LOC = "P20";	Slide switch 7 input
NET "switch<0>"	PULLUP;	Internal pull-up resistor
NET "switch<1>"	PULLUP;	Internal pull-up resistor
NET "switch<2>"	PULLUP;	Internal pull-up resistor
NET "switch<3>"	PULLUP;	Internal pull-up resistor
NET "switch<4>"	PULLUP;	Internal pull-up resistor
NET "switch<5>"	PULLUP;	Internal pull-up resistor
NET "switch<6>"	PULLUP;	Internal pull-up resistor
NET "switch<7>"	PULLUP;	Internal pull-up resistor

## USER LED

The TINALab II FPGA board provides eight user LEDs.

NET "LED0" LOC = "P10";	LED is ON when signal is low
NET "LED1" LOC = "P7";	LED is ON when signal is low
NET "LED2" LOC = "P6";	LED is ON when signal is low
NET "LED3" LOC = "P5";	LED is ON when signal is low
NET "LED4" LOC = "P4";	LED is ON when signal is low
NET "LED5" LOC = "P3";	LED is ON when signal is low
NET "LED6" LOC = "P141";	LED is ON when signal is low
NET "LED7" LOC = "P140";	LED is ON when signal is low

## 7-SEGMENT LED DISPLAY

The TINALab II FPGA development board utilizes four digit common-anode 7-segment (numeric) LED displays that can be used during the test and debugging phase of a design. All of these segments are active-low meaning that a LED will glow when a low logic level is applied to it. Since the segment signals are also common, only one selected digit glow at a time, but if the digits are switched one after the other fast in multiplexed mode all the digits seem to be still virtually.

NET "Digit0" LOC = "P51";	4-digit numeric LED display, digit1
NET "Digit1" LOC = "P50";	4-digit numeric LED display, digit2
NET "Digit2" LOC = "P48";	4-digit numeric LED display, digit3
NET "Digit3" LOC = "P47";	4-digit numeric LED display, digit4
NET "DISPA" LOC = "P43";	4-digit numeric LED display, segment A
NET "DISPB" LOC = "P41";	4-digit numeric LED display, segment B
NET "DISPC" LOC = "P29";	4-digit numeric LED display, segment C
NET "DISPD" LOC = "P27";	4-digit numeric LED display, segment D
NET "DISPE" LOC = "P26";	4-digit numeric LED display, segment E
NET "DISPF" LOC = "P42";	4-digit numeric LED display, segment F
NET "DISPG" LOC = "P40";	4-digit numeric LED display, segment G
NET "DISPDP" LOC = "P28";	4-digit numeric LED display, decimal point

## RS232 SERIAL PORT

The TINALab FPGA development board provides an RS232 port that can be driven by the Spartan-II FPGA. A subset of the RS232 signals are used on the Spartan-II development board to implement this interface with the transmit and receive serial data streams (TXD and RXD, respectively) as well as the flow control signals (RTS and CTS, respectively).

The board provides a DB-9 connection (J5) for a simple RS232 port. This board utilizes the Analog Devices ADM3202 RS232 driver for driving the signals. The pin functions on the RS-232 port are identical to those found on a PC serial port, so a null modem cable that swaps the TXD/RXD and CTS/RTS lines is needed if the TINALab II FPGA board and PC are to communicate. The user provides the RS232 UART code, which resides in the Spartan-II FPGA.

NET "RXD" LOC = "P120";	Data transmitted by FPGA
NET "TXD" LOC = "P122";	Data received by FPGA
NET "CTS" LOC = "P123";	Clear to send by the FPGA
NET "RTS" LOC = "P121";	Request to send to the FPGA

## VGA DISPLAY PORT

The FPGA can generate a video signal for display on a VGA monitor. When the FPGA is generating VGA signals, the FPGA outputs two bits each of red, green, and blue color information to a simple resistor-ladder DAC. The outputs of the DAC (J11) are sent to the RGB inputs of a VGA monitor along with the horizontal and vertical sync pulses (/HSYNC, /VSYNC) from the FPGA. You have to create a VGA driver circuit for your TINALab FPGA board to actually display a 64-color image.

NET "red0"	LOC = "P134";	
NET "red1"	LOC = "P133";	
NET "green0"	LOC = "P132";	
NET "green1"	LOC = "P131";	
NET "blue0"	LOC = "P130";	
NET "blue1"	LOC = "P129";	
NET "vsync"	LOC = "P124";	
NET "hsync"	LOC = "P126";	

## PS/2 MOUSE/KEYBOARD PORT

The TINALab FPGA Board provides a PS/2-style interface (mini-DIN connector J10) to either a keyboard or a mouse. The FPGA receives two signals from the PS/2 interface: a clock signal and a serial data stream that is synchronized with the falling edge of the clock. Older keyboards or mice work from 5V. In this case the JP5 jumper should be close pin 2, 3.

NET "PS2Clk"	LOC = "P44";	
NET "PS2Data"	LOC = "P46";	

## R/2R LADDER DAC

D/A converter converts digital quantities to an analog voltage. FPGA drives a R/2R ladder resistive network to generate analog signal on JP3. If the code 0001 (DAC3..1=000, DAC0 = 1) is applied to the inputs of the R/2R network, the output voltage will be approximately 0.21V. From this step voltage, the output voltage of the ladder network can be calculated by 0.21V by number applied, in range of 0 to 15. DAC0 the least and DAC3 the most significant value in the binary representation.

NET "DAC0"	LOC = "P54";	
NET "DAC1"	LOC = "P56";	
NET "DAC2"	LOC = "P58";	
NET "DAC3"	LOC = "P59";	

## GENERIC USER I/O

The following pins can be connected to TINALab II Digital Signal Generator by a ribbon cable through J2 block header as inputs or can be used freely as generic.

NET "DIn<0>"	LOC = "P86";	
NET "DIn<1>"	LOC = "P87";	
NET "DIn<2>"	LOC = "P84";	
NET "DIn<3>"	LOC = "P85";	
NET "DIn<4>"	LOC = "P80";	
NET "DIn<5>"	LOC = "P83";	
NET "DIn<6>"	LOC = "P78";	
NET "DIn<7>"	LOC = "P79";	
NET "DIn<8>"	LOC = "P76";	
NET "DIn<9>"	LOC = "P77";	
NET "DIn<10>"	LOC = "P74";	
NET "DIn<11>"	LOC = "P75";	
NET "DIn<12>"	LOC = "P65";	
NET "DIn<13>"	LOC = "P66";	
NET "DIn<14>"	LOC = "P60";	
NET "DIn<15>"	LOC = "P64";	

The following pins can be connected to TINALab II Logic Analyzer by a ribbon cable through J1 block header as outputs or can be used freely as generic I/O.

NET "DOut<0>"	LOC = "P118";	
NET "DOut<1>"	LOC = "P117";	
NET "DOut<2>"	LOC = "P116";	
NET "DOut<3>"	LOC = "P115";	
NET "DOut<4>"	LOC = "P114";	
NET "DOut<5>"	LOC = "P113";	
NET "DOut<6>"	LOC = "P112";	
NET "DOut<7>"	LOC = "P103";	
NET "DOut<8>"	LOC = "P102";	
NET "DOut<9>"	LOC = "P101";	
NET "DOut<10>"	LOC = "P100";	
NET "DOut<11>"	LOC = "P99";	
NET "DOut<12>"	LOC = "P96";	
NET "DOut<13>"	LOC = "P95";	
NET "DOut<14>"	LOC = "P94";	
NET "DOut<15>"	LOC = "P93";	


## QUICK START

If you use TINALab Spartan board together with TINA circuit simulation software and TINALab II High Speed Multifunction PC Instrument there is possible to develop VHDL code with simulation capabilities and after implementing, you can download your design and measure back the signals with the help of TINALab II Digital Signal Generator and Logic Analyzer. TINA provides code developing, simulation and measurement control with TINALab II, which does power supplies and signal link.

To generate FPGA downloadable configuration file, you will need Xilinx ISE *Webpack*<sup>TM</sup> software ([http://www.xilinx.com/ise/logic\\_design\\_prod/webpack.htm](http://www.xilinx.com/ise/logic_design_prod/webpack.htm)).


The following examples apply TINA 8 and Xilinx ISE *WebPACK*<sup>TM</sup> 10.1.02.

1. Connect TINALab II with your XC2S FPGA card as described under TINALab II User Port on page 7.
2. Open the \examples\vhdl\fpga\full\_add.tsc sample design.
3. Press the VHD button on the toolbar to enter interactive mode.
4. Toggle the switches to change the logic low and high levels on the input of the adder. Depending on the state of the inputs the outputs change state as the function of the full adder.
5. Now, create the VHDL program source for the FPGA card.  
Press T&M > Create VHD & UCF file... Save the vhd and ucf file.
6. Start Xilinx ISE *WebPACK*<sup>TM</sup> and create a new project (File > New project...) with the following settings.  
Project name: Full\_Add  
Project location: [Setting Folder]\VHDL\Projects2\e\_FULL\_ADD\_entity (See Settings Folder value View > Editor Options > Environment Variables.)  
Top-level source type: HDL  
Click Next.
7. Fill the Device Properties dialog. Note, - that Device should exactly match the FPGA type mounted on the board.




Click Next then Next again to skip the “Add New Source” window.

8. Add the vhd and ucf files as existing sources to the projects.



Click Next until Finish.


9. Select the e\_FULL\_ADD\_entity-a\_FULL\_ADD\_arch architecture source in the “Sources in Project” window, and then click the right button on “Generate Programming File” in the Process window. Select “Rerun All”. *WebPACK*<sup>TM</sup> will synthesize and implement the circuit into a bitstream file.



10. Now, choose T&M > Download to FPGA Card... in the TINA program. Select the e\_full\_add\_entity.bit file from your ISE project directory, and then click Open. TINA will download the configuration file on the board; the DONE LED light will come up.
11. Play the slide switches (A - SWITCH0, B – SWITCH1) to assign H, L logic values to the circuit input. LED0 will be on when Sum value is logic 1, as LED1 Co (carry out).


In a mixed environment, where the circuitry is not pure digital, follow the steps below.

1. Connect TINALab II with your XC2S FPGA card as described under TINALab II User Port on page 7.
2. Open the \EXAMPLES\VHDL\FPGA\FPGA\_Wave\_Generator.TSC sample design.




The main digital logic (Digital wave) generates sine or saw binary sample values which are fed into an R/2R resistor ladder network to form analog output signal on node DAC output. The resistors functions as simple DAC, they are mounted on the FPGA board. The  $R_p$  and  $C_p$  components are to model the TINALab II Oscilloscope Probe. If we perform measurement by the instrument on the card, the Probe will affect the output signal. The PreScaler divides 50M to 1MHz.


3. Now, set the 'Digital wave' enable input to H and sel to L. Switch Probe off. Run transient simulation: Anlysis > Transient... Enter 100u to the End Display value. Run transient calculation with Probe on. As a result of calculating with the oscilloscope probe, which imposes a loading of a parallel RC network, the step-like shape of the curve rolls more slowly. The probe filters the high frequencies.  
Note, the digital outputs are powered by VCCIO which value (3.3V) is identical that of the FPGA chip is supplied on the board.



4. To create the VHDL program source for the FPGA card, remove analog components: the Digital wave supply, all the passives and the switch.  
Press T&M > Create VHD & UCF file... Save the vhd and ucf file.
5. Start Xilinx ISE *WebPACK*<sup>TM</sup> and create a new project (File > New project...) with the following settings.  
Project name: FPGA\_Wave\_Generator  
Project location: [Setting Folder]\VHDL\Projects2\e\_FPGA\_Wave\_Generator\_entity  
(See Settings Folder value View > Editor Options > Environment Variables.)  
Top-level source type: HDL  
Click Next. From now on the steps are identical with those of the previous example until creating configuration bitstream to download.
6. After downloading the .bit file by TINA, let us measure the output signal in real. Set the switches on the board to the same position they were during the simulation and connect ChA input of TINALab II with the supplied probe to JP3, the ladder DAC output. Note, the switch in the probe handle must be in 10X attenuation. For the correct displaying, set the probe attenuation in the software also: T&M > Options... > HW Setup.



At last, start Oscilloscope: T&M > Oscilloscope > Real. Use Normal trigger mode on channel A with 1.5V trigger level. You might switch on 'Store' to get better display result from the collected samples.



7. Stop the oscilloscope then click on the Export curves button. The Diagram Window will come up. Copy the curves into the same diagram.

